



85" SMART DIGITAL SIGNAGE

85PUD20A









QUICK REFERENCE GUIDE




Thank you for purchasing the unit.

Safety Instruction



- 1. **Read Instructions** - All the safety and operating instructions should be read before the appliance is operated.
- 2. **Retain Instructions** - The safety and operating instructions should be retained for future reference.
- 3. **Heed Warnings** - All warnings on the appliance and in the operating instructions should be adhered to.
- 4. **Follow Instructions** - All operating instructions should be followed.
- 5. **Battery** - Batteries shall not be exposed to excessive heat such as sunshine, fire or the like.
- 6. **Earthing Connection** - The apparatus shall be connected to a MAINS socket outlet with a protective earthing connection.
- 7. **Water and Moisture** - The appliance should not be used near water.
- 8. **Ventilation** - The appliance should be well situated so that its location or position does not interfere with its proper ventilation.
- 9. **Heat** - This appliance should be placed away from heat sources such as radiators, heat registers and stoves.
- 10. **Power Sources** - The appliance should only be connected to a power supply as described in the operating instructions or as marked on the appliance.
- 11. **Grounding or Polarization** - Precautions should be taken.
- 12. **Power Cord Protection** - Power supply cord should be located so that it is not likely to be walked on, or pinched by items placed upon it.
- 13. **Cleaning** - The appliance should be cleaned only as recommended by the manufacturer.
- 14. **Non-use Periods** - The power cord of the appliance should be unplugged from the outlet when left unused for a long period of time.
- 15. **Objects and Liquids** - Care should be taken so that objects do not fall, and liquids are not spilled into the enclosure through openings.
- 16. **Conditions Requiring Service** - The appliance should be serviced by qualified service personnel when:
 - The power-supply cord or the plug has been damaged.
 - Objects have fallen on or liquid has been spilled into the appliance.
 - The appliance has been exposed to rain.
 - The appliance does not appear to operate normally or exhibits a marked change in performance.
- 17. This appliance should not be exposed to water and no objects filled with liquids such as a vase should be placed on the unit. Where the mains plug or an appliance coupler is used as the disconnect device, the disconnect device shall remain readily operable.
- 18. Only for indoor used. (🏠).
- 19. **Caution** - There is a button cell inside. Place away from the old and kids, avoiding to be eaten by mistake. Once happened, please go to hospital for treating immediately.
- 20. Keep the key properly. There are high voltage and dangerous live parts inside. It's better to maintain and repair with a professional.

 <p>Warning</p> <p>High voltages are used in the operation of this product. Do not remove the back cover of the cabinet. Refer servicing to qualified service personnel.</p>	 <p>Warning</p> <p>To prevent fire or electrical shock hazard, do not expose the main unit to rain or moisture.</p>	 <p>Warning</p> <p>Do not insert foreign objects into the television's slots or openings. Never spill any kind of liquid on the television receiver.</p>
 <p>Caution</p> <p>If the television is placed into a confined space, ensure that the minimum distances are observed as shown. Heat build up can reduce the service life of your television, and can also be dangerous.</p>	 <p>Caution</p> <p>Never stand on, lean on, push or apply force to the product or its stand. You should pay special attention to children.</p>	 <p>Caution</p> <p>Do not place the main unit on an unstable cart stand, shelf or table. Serious injury to an individual, and damage to the television, may result should it fall.</p>

 <p>Caution</p> <p>When the product is not used for an extended period of time, it is advisable to disconnect the AC power cord from the AC outlet.</p>	 <p>Caution</p> <p>Avoid exposing the main unit to direct sunlight and other sources of heat. Do not position television receiver directly on other products which give off heat e.g. video cassette players, audio amplifiers. Do not block the ventilation holes in the back cover. Ventilation is essential to prevent electrical failure. Do not squash power supply cord under the main unit.</p>	 <p>Caution</p> <p>The panel used in this product is made of glass. It can break if the product is dropped or if force is applied to the panel. Individuals should exercise caution when dealing with broken glass should the panel break.</p>
--	--	--

Exemptions

- Cybercast is not liable for any damage caused by fires, natural disaster (such as thunderstorms, earthquake, etc.), acts by the third parties, accidents, owner's misuse or use in other improper conditions.
- Cybercast is not liable for incidental damages (such as profit loss or interruption in business, modification or erasure of record data, etc.) caused by use or inability to use of product.
- Cybercast is not liable for any damage caused by neglect of the instructions described in the owner's manual.
- Cybercast is not liable for any damage caused by misuse or malfunction through simultaneous use of this product and the connected equipment.

Introduction

Thank you for purchasing the unit. Your unit will bring you years of high-quality viewing enjoyment. The appliance is easy to operate and provides exceptionally high quality image. The manual will explain the operation of the unit, including its functions, features and other important features. Before installing or operating your unit, please take the time to thoroughly read this manual, particularly the sections on safety.

Thanks for purchasing the unit. The latest news, software, utility, driver, product, manual and Q&A will be found at Cybercast website.




[Http://www.cybercast.com.au](http://www.cybercast.com.au)

Wall-mount Installation

1. Install the mount, as shown in figure(1). Make sure that the supporting surface will safely support the combined load of the equipment and all attached hardware and components.
2. Install the bracket, as shown in figure(2).
3. Place the TV with bracket on the mount, as shown in figure(3).


The above installation methods are for reference only! Installation methods may be different depending on the actual mounting situation.

Highly recommend consult or ask the professionals to install!




Connecting the Power Cord

Connect the power cord directly to the wall outlet.



Port Instruction



Power On the Unit

Connect the Power Cord to the Power Outlet. Press the POWER Button on the Remote Control or STANDBY Button on the unit to turn on the TV.

POWER Button




Remote Control




STANDBY Button


Package Contents




Main Unit




STAND X 2



Remote Control
AAA Batteries(x2)



Power Cord



1pc Warranty
Card

Specification

Power Source	~100-240V AC, 50/60Hz	
Max. Power Consumption	230W	
Panel Spec	Active Display Area	1872mm(H) x 1053mm(V)
	Panel Native Resolution	3840 x 2160 pixels
	Brightness	400 cd/m ²
	Contrast Ratio	5000:1
	Ratio	16 : 9
Input/Output	TF-Card	TF x 1
	USB	USB 2.0 x 2
	RJ45	RJ45 x 1
	HDMI INPUT	HDMI INPUT x 1
Android System Specification	OS	Android 6.0
	CPU	MSTAR SD6A648, A53*4 core
	DDR SIZE	2GByte
	eMMC Flash	8GByte
Audio Power	8 oh 20W	
Unit Dimension	1956(L) x 1126(W) x 101(H)mm	

HOTLINE

• AUSTRALIA

: www.soniq.com/au/contact-us

• NEW ZEALAND

: www.soniq.com/nz/contact-us