

150mm

210mm

Thanks for purchasing the unit. Your unit integrates digital and analog tuner in the same unit. You can enjoy both digital and analog broadcasting under following set-up easily.

The latest news, software, utility, driver, product, manual and Q&A will be found at SONIQ website.


[Http://www.soniq.com](http://www.soniq.com)

**Stand Installation**

Before performing work, please lay the TV on the stand to prevent it from being damaged.


Fix the stand and the unit together with screws. To remove the stand, reverse instruction as above

Black Screws: 4X18BA(X5)



**Antenna Connection**

Your simply connect outdoor antenna to ANT IN to receive broadcasting signals.



150mm

**RF Remote Control pairing**

The Remote Control has already been paired for the first time you use it therefore users do not need to perform this step again under normal conditions, but if it does not work with battery fully charged or if you have replaced the Remote Control or **2.4G QT166 RF DONGLE** before operating then follow the steps below.


1. Turn on the power at the left side of Remote Control (pairing will take effect in one minute), and hold the Remote Control within 1 meter of the unit.
2. Press and hold RF Button for 2 seconds, indicator light 3 will flash and light up together with indicator light 2.
3. Plug **2.4G QT166 RF DONGLE** into the USB port on TV/USB port on the computer.
4. Pairing will complete within 3 minutes, if indicator light 3 and 2 flashes 3 times, that means the device has been paired successfully. If indicator light lights up all the time or goes out, that means the pairing failed. In which case please unplug the **2.4G QT166 RF DONGLE**, and repeat the above steps for pairing.

**Remote Control Function**


1. Turn the Power Switch ON at the left side of the Remote Control, the indicator light 3 will flash 3 times, meaning you can operate the Remote Control.
2. Press and hold any key to light up indicator light 3, the light will go out when releasing the button.
3. RF Remote Control is supplied with lithium battery. **Indicator light 2 flashing means low power**, please charge immediately.
4. Plug in USB cable (supplied with the TV) for charging, then connect to the remote control/PC/adaptor with the current of 5V/1A. Indicator light 1 lights up when charging is required. Indicator light 1 will go out when fully charged.

**Note:**

1. If a problem occurred where the RF Remote Control does not work or the arrow jumps, etc. It may be affected by interference from the nearby wireless network. In order to solve this problem, please use the USB extension cord in the packaging to connect the **2.4G QT166 RF DONGLE** to the TV port, and at the same time keep the 2.4G Remote Control separated from the unit.




150mm



**Remark:** The 2.4G USB Device **2.4G QT166 RF DONGLE** should be inserted inside the TV before operating. Users are highly recommended to use the extension cord.

**Power On the Unit**

Connect the Power Cord to the Power Outlet. Press the POWER Button on the Remote Control or STANDBY Button on the unit to turn on the TV.




**TV Auto Scan**

You can perform Analog TV Auto Search Program at below methods.

Method 1:

1. Initial Setup window will be appeared when you first start to use.
2. Press **◀▶** button to select the Country, then press OK Button to proceed.
3. Press **▲▼** button to select your location, and then press OK button to proceed.
4. Use **▲/▼** button to select the tuning type, press OK for channel tuning.
5. Press **▲/▼** button to select the setting mode you want, then press OK to start channel tuning.

150mm



Method 2:

Press SOURCE Button to display the Source list


Press **▲/▼** button to select ATV and

Press OK button to confirm.

Press MENU Button to enter the CHANNEL page as follows:

1. Auto Tuning will be highlighted by entering this screen. Press to continue.
2. Press **◀▶** button to select country, press OK Button to continue.
3. Use **▲/▼** button to select your location, then press OK button to enter the next step.

150mm



For specific operation instruction, please refer to the Instruction Manual.

1. Press HOME button to visit the HOME page.
2. Select the Instruction Manual at the bottom of the application menu.

Press OK button or LEFT MOUSE button to view the Instruction Manual.

